



80UC and 98 RH Night Depository Replacement Guide

Best in the class replacements heads



est. 1967

HAMILTON

CUSTOM MADE SECURITY

Night Depository Replacement Guide



Diebold - Cashgard
 Replace With: 80UC
 Kit: B6883
 Instructions: N/A



Fortis - AHD106
 Replace With: 80UC
 Kit: N/A
 Instructions: N/A



Fortis - AHDR 509
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A



Hamilton - 68F
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A



Hamilton - 67R
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A



Hamilton - 68B
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A



Mosler - American
 Replace: 98RH
 Kit: B6379
 Instructions: 08-328



Mosler - C77-DF
 Replace With: 98RH
 Kit: B6387
 Instructions: Doc
 #08-329



Mosler - C77-DR
 Replace With: 98RH
 Kit: B6394
 Instructions: Doc
 #08-330



Mosler - C77-ER
 Replace With: N/A
 Kit: N/A
 Instructions: N/A



Mosler - Century
 Replace With: 98RH
 Kit: 96-470
 Instructions: Doc
 #08-331



Mosler Magna Dual
 Replace: 80UC
 Kit: 96-450
 Instructions: N/A



Mosler - Universal
 Replace With: N/A
 Kit: N/A
 Instructions: N/A



National - Flush
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A



National - Recessed
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A



Security Corporation - ND-11
 Replace With: 98RH
 Kit: 96-448
 Instructions: N/A



SSE
 Replace With: 80UC
 Kit: N/A
 Instructions: N/A



SSE - Replacement Head
 Replace With: N/A
 Kit: N/A
 Instructions: N/A



Kumahira - ND-61
 Replace With: N/A
 Kit: N/A
 Instructions: N/A



Securifort
 Replace With: 98RH-20
 Kit: 14-012-CANADA
 Instructions: 14-012 USA



National – Flush
 Replace with: 98RH
 Kit: N/A
 Instructions: N/A



National – Recessed
 Replace with: 98RH
 Kit: N/A
 Instructions: N/A



Chubb "T" Trap
 Replace with: 98RH-20
 Kit: 96-798 CANADA
 Kit: 96-959 USA



TANN-NDH-100
 Replace with: 98RH-20
 Kit: 96-919 CANADA
 Instructions: N/A



Chubb – Citadel c6
 Replace with: 98RH-20
 Kit: 96-813 USA
 Kit: 96-794 CANADA



MGM
 Replace with: 98RH-20
 Kit: 96-705
 Instructions: N/A



**American 85–
 Short (Waco)**
 Replace with: N/A
 Kit: 14-005 CANADA
 Kit: 14-006 USA



**American 85–
 ADANAC**
 Replace with: 98RH-20
 Kit: 96-963 ADANAC USA
 Kit: 96-922 CANADA



**Diebold Polaris
 Over and Under**
 Replace with: 98RH-20
 Kit: 96-824 CANADA
 Instructions: USA N/A



**Diebold Polaris
 Side by Side**
 Replace with: 98RH-20
 Kit: 96-802 CANADA
 Instructions: USA N/A



Chubb "Q"
 Replace with:
 98RH-20
 Kit: 96-830 USA
 Kit: 96-758
 CANADA



**Diebold Securomatic
 Trap**
 Replace with: 98RH-20
 Kit: 96-757 CANADA
 Kit: 96-890 USA
 Instructions: 96-757



**Chubb "Q"
 Envelope
 (Right Side)**
 Replace with:
 98RH-20
 Kit: 96-939



**Chubb "Q"
 Without
 Brass Trim**
 Replace with:
 98RH-20
 Kit: 96-862



T With Lower Locker
 Replace with: 98RH-20
 Kit: 14-029 CANADA
 (With Lower Locker)
 Kit: 14-030 USA
 (With Lower Locker)
 Kit: 14-037
 (Lower Locker Only)
 Kit: 96-798 CANADA
 (With Out Lower Locker)
 Kit: 96-959 USA
 (With Out Lower Locker)
 Kit: 96-973-TRIM (Trim only)
 Kit: 96-972 (Locker cover only)



**Diebold Polaris
 Over and Under
 with Clearing Safe**
 Replace with:
 98RH-20
 Kit: 96-956
 Instructions:
 USA N/A



Eagle 103
 Replace with:
 98RH-20
 Kit: 14-180



J-head
 Replace with:
 98RH-20
 Kit: 14-181



Fortis 5084
 Replace with:
 98RH-20
 Kit: 14-188



ACCESS
 Replace with:
 98RH-20
 Kit: 96-960
 Instructions: N/A



Lefebure - 101
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A

Lefebure - 201
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A

Lefebure - 312
 Replace N/A
 Kit: N/A
 Instructions: N/A

Lefebure - 412
 Replace 80UC
 Kit: B6883
 Instructions: N/A

Lefebure - 577
 Replace N/A
 Kit: N/A
 Instructions: N/A



Lefebure - 612
 Replace With: 98RH
 Kit: B6357
 Instructions: Doc #08-327

Mosler Magna Bag Only
 Replace: With 98RH
 Kit: B6379
 Instructions: 08-328

Allied - Nightwatch Dual
 Replace With: 98RH
 Kit: 96-440
 Instructions: N/A

American Vault - 85
 Replace With: 80UC
 Kit: B6883
 Instructions: N/A



Chubb/Diebold-Citadel
 Replace With: 80UC
 Kit: N/A
 Instructions: N/A

Collier - ND1000
 Replace With: 98RH
 Kit: 96-449
 Instructions: N/A

Collier - ND2000/ND2010
 Replace With: 80UC
 Kit: 96-475
 Instructions: N/A

Diebold Eagle Bag Only
 Replace With: 98RH
 Kit: Not Needed
 Instructions: N/A

Diebold- Eagle 103 Dual Flush
 Replace With: 98RH
 Kit: None Needed
 Instructions: Doc #08-326



Diebold - Eagle 103 Dual Recessed
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A

Diebold - Polaris Flush
 Replace With: 98RH
 Kit: B6358
 Instructions: Doc #08-325

Diebold - Polaris Flush Bag Only
 Replace With: 98RH
 Kit: None Needed
 Instructions: N/A

Diebold - Polaris Recessed
 Replace With: 98RH
 Kit: B6406
 Instructions: N/A

Diebold - Securomatic
 Replace With: 80UC (98RH)
 Kit: 96-451 (B10374)
 Instructions: Doc #08-323



Manufacturers and providers of the latest in drive-up systems, modular vaults, vault doors, night depositories, physical security containers, alarm systems, safe deposit boxes, cash management and surveillance equipment.

7775 Cooper Road | Cincinnati, OH 45242
 Phone 513.874.3733

hamiltonsecurity.com