



"Oakley" Night Depository Replacement Guide

Best in the class replacement heads



HAMILTON
BY **GUNNEBO**®

Night Depository Replacement Guide



Diebold – Cashgard

Replace With: OAK80
Kit: B6883
Instructions: N/A



Diebold Securomatic Trap

Replace with: OAK-20
Kit: 96-757
Instructions: 96-757



Diebold Polaris Over and Under

Replace with: OAK-20
Kit: 96-824
Instructions: N/A



Diebold Polaris Over and Under with Clearing Safe

Replace with: OAK-20
Kit: 96-956
Instructions: N/A



Diebold Polaris Side by Side

Replace with: OAK-20
Kit: 96-802
Instructions: N/A



Diebold Eagle Bag Only

Replace With: OAK-98
Kit: *(Not needed)*
Instructions: N/A



Diebold– Eagle 103 Dual Flush

Replace With: OAK-98
Kit: *(Not needed)*
Instructions: Doc #08-326



Diebold – Eagle 103 Dual Recessed

Replace With: OAK-98
Kit: N/A
Instructions: N/A



Diebold – Polaris Flush

Replace With: OAK-98
Kit: B6358
Instructions: Doc #08-325



Diebold – Polaris Flush Bag Only

Replace With: OAK-98
Kit: *(Not needed)*
Instructions: N/A



Diebold – Polaris Recessed

Replace With: OAK-98
Kit: B6406
Instructions: N/A



Diebold – Securomatic

Replace With: OAK80
Kit: 96-451 (B10374)
Instructions: Doc #08-323



Chubb/Diebold– Citadel

Replace With: OAK80
Kit: N/A
Instructions: N/A

DieBold



Fortis – AHD106

Replace With: OAK80
Kit: N/A
Instructions: N/A



Fortis – AHDR 509

Replace With: OAK-98
Kit: N/A
Instructions: N/A



Fortis 5084

Replace with: OAK-20
Kit: 14-188
Instructions: N/A
(Call for lead time)

Fortis



Mosler- American

Replace With: OAK-98
Kit: B6379
Instructions: Doc #08-328



Mosler – C77-DF

Replace With: OAK-98
Kit: B6387
Instructions: Doc #08-329



Mosler – C77-DR

Replace With: OAK-98
Kit: B6394
Instructions: Doc #08-330



Mosler – C77- ER

Replace With: OAK80
Kit: N/A
Instructions: N/A



Mosler Magna Bag Only

Replace With: OAK-98
Kit: B6379
Instructions: 08-328



Mosler – Century

Replace With: OAK-98
Kit: 96-470
Instructions: Doc #08-331



Mosler Magna Dual Recessed

Replace With: OAK80
Kit: 96-450
Instructions: N/A



Mosler – Universal

Replace With: N/A
Kit: N/A
Instructions: N/A

Mosler



National – Flush

Replace With: OAK-98
Kit: N/A
Instructions: N/A



National Recessed

Replace With: OAK-98
Kit: N/A
Instructions: N/A



National

Replace with: OAK-20
Kit: 24-104
Instructions: N/A

National



Chubb "T" Trap

Replace with: OAK-80
Kit: 96-798
Instructions: N/A



Chubb - Citadel c6

Replace with: OAK-20
Kit: 96-794
Instructions: N/A



Chubb "Q"

Replace with: OAK-20
Kit: 96-758
Instructions: N/A
(Call for lead time)



Chubb "Q" Envelope (Right Side)

Replace with: OAK-20
Kit: 96-939
Instructions: N/A
(Call for lead time)



Chubb "Q" Without Brass Trim

Replace with: OAK-20
Kit: 96-862
Instructions: N/A
(Call for lead time)

Chubbsafes



Lefebure - 101

Replace With: OAK-98
Kit: N/A
Instructions: N/A



Lefebure - 201

Replace With: OAK-98
Kit: N/A
Instructions: N/A



Lefebure - 312

Replace With: N/A
Kit: N/A
Instructions: N/A



Lefebure - 412

Replace With: OAK80
Kit: B6883
Instructions: N/A



Lefebure - 577

Replace With: N/A
Kit: N/A
Instructions: N/A



Lefebure - 612

Replace With: OAK-98
Kit: B6357
Instructions: Doc #08-327

LeFEBURE



American 85 - Short (Waco)

Replace with: OAK-20
Kit: 14-005
Instructions: N/A



American 85-ADANAC-Young Ann

Replace with: OAK-20
Kit: 96-963
Instructions: N/A



American Vault - 85

Replace With: OAK80
Kit: B6883
Instructions: N/A

American Vault



Hamilton – 68F

Replace With: OAK-98
Kit: N/A
Instructions: N/A



Hamilton – 67R

Replace With: OAK-98
Kit: N/A
Instructions: N/A



Hamilton – 68B

Replace With: OAK-98
Kit: N/A
Instructions: N/A

HAMILTON

Other Competitors



Security Corporation – ND-11

Replace With: OAK-98
Kit: 96-448
Instructions: Doc #08-331



SSE

Replace With: OAK80
Kit: N/A
Instructions: N/A



SSE – Replacement Head

Replace With: N/A
Kit: N/A
Instructions: N/A



Kumahira – ND-61

Replace With: N/A
Kit: N/A
Instructions: N/A



Lane L247A

Replace with: OAK80
Kit: 24-103
Instructions: N/A



TANN-NDH-100

Replace with: OAK-20
Kit: 96-919
Instructions: N/A
(Call for lead time)



MGM

Replace with: OAK-20
Kit: 14-010
Instructions: N/A



Eagle 103

Replace with: OAK-20
Kit: 14-180
Instructions: N/A
(Call for lead time)



T With Lower Locker

Replace with: OAK-20
Kit: 14-029
(With Lower Locker)
Kit: 14-037
(Lower Locker Only)
Kit: 96-798
(With Out Lower Locker)
Kit: 96-973-TRIM (Trim only)
Kit: 96-972 (Locker cover only)



Allied – Nightwatch Dual

Replace With: OAK-98
Kit: 96-440
Instructions: N/A



Collier – ND1000

Replace With: OAK80
Kit: 96-449
Instructions: N/A



**Collier – ND2000/
ND2010**

Replace With: OAK80
Kit: 96-475
Instructions: N/A



J-head

Replace with: OAK-20
Kit: 14-181
Instructions: N/A
(Call for lead time)



Securifort

Replace With: OAK-20
Kit: 14-012
Instructions: N/A
(Call for lead time)



ACCESS

Replace with: OAK-20
Kit: 96-960
Instructions: N/A
(Call for lead time)



MGM Deep

Replace With: OAK-20
Kit: 15-058
Instructions: N/A

HAMILTON
BY **GUNNEBO**[®]



1030 Round Bottom Road | Milford, OH 45150 | 513.874.3733

hamiltonsecuritysolutions.com

Form 551 Rev. 03-24