



# "Oakley" Night Depository Replacement Guide

Best in the class replacement heads



**HAMILTON**  
BY **GUNNEBO**®

# Night Depository Replacement Guide



## Diebold – Cashgard

Replace With: OAK80  
Kit: B6883  
Instructions: N/A



## Diebold Eagle Bag Only

Replace With: OAK-98  
Kit: *(Not needed)*  
Instructions: N/A



## Diebold– Eagle 103 Dual Flush

Replace With: OAK-98  
Kit: *(Not needed)*  
Instructions: Doc #08-326



## Diebold – Eagle 103 Dual Recessed

Replace With: OAK-98  
Kit: N/A  
Instructions: N/A



## Diebold – Polaris Flush

Replace With: OAK-98  
Kit: B6358  
Instructions: Doc #08-325



## Diebold – Polaris Flush Bag Only

Replace With: OAK-98  
Kit: *(Not needed)*  
Instructions: N/A



## Diebold – Polaris Recessed

Replace With: OAK-98  
Kit: B6406  
Instructions: N/A



## Chubb/Diebold-Citadel

Replace With: OAK80  
Kit: N/A  
Instructions: N/A



## Diebold – Securomatic

Replace With: OAK80  
Kit: 96-451 (B10374)  
Instructions: Doc #08-323



## Diebold Polaris Over and Under with Clearing Safe

Replace with: OAK-20  
Kit: 96-956  
Instructions: N/A



## Diebold Polaris Over and Under

Replace with: OAK-20  
Kit: 96-824  
Instructions: N/A



## Diebold Securomatic Trap

Replace with: OAK-20  
Kit: 96-757  
Instructions: 96-757



## Diebold Polaris Side by Side

Replace with: OAK-20  
Kit: 96-802  
Instructions: N/A

DieBold

DieBold  
**(20in.)**



**Fortis – AHD106**

Replace With: OAK80  
Kit: N/A  
Instructions: N/A



**Fortis – AHDR 509**

Replace With: OAK-98  
Kit: N/A  
Instructions: N/A



**Fortis 5084**

Replace with: OAK-20  
Kit: 14-188  
Instructions: N/A  
*(Call for lead time)*

# Fortis



**Mosler- American**

Replace With: OAK-98  
Kit: B6379  
Instructions: Doc #08-328



**Mosler – C77-DF**

Replace With: OAK-98  
Kit: B6387  
Instructions: Doc #08-329



**Mosler – C77-DR**

Replace With: OAK-98  
Kit: B6394  
Instructions: Doc #08-330



**Mosler – C77- ER**

Replace With: OAK80  
Kit: N/A  
Instructions: N/A



**Mosler Magna Bag Only**

Replace With: OAK-98  
Kit: B6379  
Instructions: 08-328



**Mosler – Century**

Replace With: OAK-98  
Kit: 96-470  
Instructions: Doc #08-331



**Mosler Magna Dual Recessed**

Replace With: OAK80  
Kit: 96-450  
Instructions: N/A



**Mosler – Universal**

Replace With: N/A  
Kit: N/A  
Instructions: N/A

# Mosler



**National – Flush**

Replace With: OAK-98  
Kit: N/A  
Instructions: N/A



**National Recessed**

Replace With: OAK-98  
Kit: N/A  
Instructions: N/A



**National**

Replace with: OAK-20  
Kit: 24-104  
Instructions: N/A

# National



**Chubb "T" Trap**

Replace With: OAK20  
Kit: 96-798  
Instructions: N/A



**Chubb - Citadel c6**

Replace with: OAK-20  
Kit: 96-794  
Instructions: N/A



**Chubb "Q"**

Replace with: OAK-20  
Kit: 96-758  
Instructions: N/A  
*(Call for lead time)*



**Chubb "Q" Envelope (Right Side)**

Replace with: OAK-20  
Kit: 96-939  
Instructions: N/A  
*(Call for lead time)*



**Chubb "Q" Without Brass Trim**

Replace with: OAK-20  
Kit: 96-862  
Instructions: N/A  
*(Call for lead time)*

# Chubbsafes



**Lefebure - 101**

Replace With: OAK-98  
Kit: N/A  
Instructions: N/A



**Lefebure - 201**

Replace With: OAK-98  
Kit: N/A  
Instructions: N/A



**Lefebure - 312**

Replace With: N/A  
Kit: N/A  
Instructions: N/A



**Lefebure - 412**

Replace With: OAK80  
Kit: B6883  
Instructions: N/A



**Lefebure - 577**

Replace With: N/A  
Kit: N/A  
Instructions: N/A



**Lefebure - 612**

Replace With: OAK-98  
Kit: B6357  
Instructions: Doc #08-327

# LeFEBURE



**American 85 - Short (Waco)**

Replace with: OAK-20  
Kit: 14-005  
Instructions: N/A



**American 85-ADANAC-Young Ann**

Replace with: OAK-20  
Kit: 96-963  
Instructions: N/A



**American Vault - 85**

Replace With: OAK80  
Kit: B6883  
Instructions: N/A

# American Vault



**Hamilton – 68F**

Replace With: OAK-98  
Kit: N/A  
Instructions: N/A



**Hamilton – 67R**

Replace With: OAK-98  
Kit: N/A  
Instructions: N/A



**Hamilton – 68B**

Replace With: OAK-98  
Kit: N/A  
Instructions: N/A

# HAMILTON

## Other Competitors



**Security Corporation – ND-11**

Replace With: OAK-98  
Kit: 96-448  
Instructions: Doc #08-331



**SSE**

Replace With: OAK80  
Kit: N/A  
Instructions: N/A



**SSE – Replacement Head**

Replace With: N/A  
Kit: N/A  
Instructions: N/A



**Kumahira – ND-61**

Replace With: N/A  
Kit: N/A  
Instructions: N/A



**Lane L247A**

Replace with: OAK80  
Kit: 24-103  
Instructions: N/A



**TANN-NDH-100**

Replace with: OAK-20  
Kit: 96-919  
Instructions: N/A  
*(Call for lead time)*



**MGM**

Replace with: OAK-20  
Kit: 14-010  
Instructions: N/A



**Eagle 103**

Replace with: OAK-20  
Kit: 14-180  
Instructions: N/A  
*(Call for lead time)*



**T With Lower Locker**

Replace with: OAK-20  
Kit: 14-029  
**(With Lower Locker)**  
Kit: 14-037  
**(Lower Locker Only)**  
Kit: 96-798  
**(With Out Lower Locker)**  
Kit: 96-973-TRIM (Trim only)  
Kit: 96-972 (Locker cover only)



**Allied – Nightwatch Dual**

Replace With: OAK-98  
Kit: 96-440  
Instructions: N/A



**Collier – ND1000**

Replace With: OAK98  
Kit: 96-449  
Instructions: N/A



**Collier – ND2000/  
ND2010**

Replace With: OAK80  
Kit: 96-475  
Instructions: N/A



**J-head**

Replace with: OAK-20  
Kit: 14-181  
Instructions: N/A  
*(Call for lead time)*



**Securifort**

Replace With: OAK-20  
Kit: 14-012  
Instructions: N/A  
*(Call for lead time)*



**ACCESS**

Replace with: OAK-20  
Kit: 96-960  
Instructions: N/A  
*(Call for lead time)*



**MGM Deep**

Replace With: OAK-20  
Kit: 15-058  
Instructions: N/A

**HAMILTON**

BY **GUNNEBO**<sup>®</sup>



1030 Round Bottom Road | Milford, OH 45150 | 513.874.3733

[hamiltonsecuritysolutions.com](http://hamiltonsecuritysolutions.com)

Form 551 Rev. 02-25