



"Oakley" Night Depository Replacement Guide

Best in the class replacement heads



est. 1967

HAMILTON
CUSTOM MADE SECURITY

A **GUNNEBO**® COMPANY

Night Depository Replacement Guide



Diebold – Cashgard

Replace With: OAK80
Kit: B6883
Instructions: N/A



Fortis – AHD106

Replace With: 80UC
Kit: N/A
Instructions: N/A



Fortis – AHDR 509

Replace With: 98RH
Kit: N/A
Instructions: N/A



Hamilton – 68F

Replace With: 98RH
Kit: N/A
Instructions: N/A



Hamilton – 67R

Replace With: 98RH
Kit: N/A
Instructions: N/A



Hamilton – 68B

Replace With: 98RH
Kit: N/A
Instructions: N/A



Mosler- American

Replace With: 98RH
Kit: B6379
Instructions: Doc #08-328



Mosler – C77-DF

Replace With: 98RH
Kit: B6387
Instructions: Doc #08-329



Mosler – C77-DR

Replace With: 98RH
Kit: B6394
Instructions: Doc #08-330



Mosler – C77- ER

Replace With: 80UC
Kit: N/A
Instructions: N/A



Mosler – Century

Replace With: 98RH
Kit: 96-470
Instructions: Doc #08-331



Mosler Magna Dual Recessed

Replace: 80UC
Kit: 96-450
Instructions: N/A



Mosler – Universal

Replace With: N/A
Kit: N/A
Instructions: N/A



National – Flush

Replace With: 98RH
Kit: N/A
Instructions: N/A



National-Recessed

Replace With: 98RH
Kit: N/A
Instructions: N/A



Security Corporation – ND-11

Replace With: 98RH
Kit: 96-448
Instructions: N/A



SSE

Replace With: 80UC
Kit: N/A
Instructions: N/A



SSE – Replacement Head

Replace With: N/A
Kit: N/A
Instructions: N/A



Kumahira – ND-61

Replace With: N/A
Kit: N/A
Instructions: N/A



Securifort

Replace With: 98RH-20
Kit: 14-012-CANADA
Instructions: 14-012 USA

****New Legend: 80UC is now OAK80 | 98RH is now OAK-98 | 98RH-20 is now OAK-20**

****New Legend: 80UC is now OAK80 | 98RH is now OAK-98 | 98RH-20 is now OAK-20**



National – Flush
Replace with: 98RH
Kit: N/A
Instructions: N/A



National – Recessed
Replace with: 98RH
Kit: N/A
Instructions: N/A



Chubb “T” Trap
Replace with: 98RH-20
Kit: 96-798 CANADA
Kit: 96-959 USA



TANN-NDH-100
Replace with: 98RH-20
Kit: 96-919 CANADA
Instructions: N/A



Chubb – Citadel c6
Replace with: 98RH-20
Kit: 96-813 USA
Kit: 96-794 CANADA



MGM
Replace with: 98RH-20
Kit: 96-705
Instructions: N/A



American 85–
Short (Waco)
Replace with: N/A
Kit: 14-005 CANADA
Kit: 14-006 USA



American 85–
ADANAC
Replace with: 98RH-20
Kit: 96-963 ADANAC USA
Kit: 96-922 CANADA



Diebold Polaris
Over and Under
Replace with: 98RH-20
Kit: 96-824 CANADA
Instructions: USA N/A



Diebold Polaris
Side by Side
Replace with: 98RH-20
Kit: 96-802 CANADA
Instructions: USA N/A



Chubb “Q”
Replace with:
98RH-20
Kit: 96-830 USA
Kit: 96-758
CANADA



Diebold Securomatic
Trap
Replace with: 98RH-20
Kit: 96-757 CANADA
Kit: 96-890 USA
Instructions: 96-757



Chubb “Q”
Envelope
(Right Side)
Replace with:
98RH-20
Kit: 96-939



Chubb “Q”
Without
Brass Trim
Replace with:
98RH-20
Kit: 96-862



TWith Lower Locker
Replace with: 98RH-20
Kit: 14-029 CANADA
(With Lower Locker)
Kit: 14-030 USA
(With Lower Locker)
Kit: 14-037
(Lower Locker Only)
Kit: 96-798 CANADA
(With Out Lower Locker)
Kit: 96-959 USA
(With Out Lower Locker)
Kit: 96-973-TRIM (Trim only)
Kit: 96-972 (Locker cover only)



Diebold Polaris
Over and Under
with Clearing Safe
Replace with:
98RH-20
Kit: 96-956
Instructions:
USA N/A



Eagle 103
Replace with:
98RH-20
Kit: 14-180



J-head
Replace with:
98RH-20
Kit: 14-181



Fortis 5084
Replace with:
98RH-20
Kit: 14-188



ACCESS
Replace with:
98RH-20
Kit: 96-960
Instructions: N/A



Lefebure – 101
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A



Lefebure – 201
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A



Lefebure – 312
 Replace N/A
 Kit: N/A
 Instructions: N/A



Lefebure – 412
 Replace 80UC
 Kit: B6883
 Instructions: N/A



Lefebure – 577
 Replace N/A
 Kit: N/A
 Instructions: N/A



Lefebure – 612
 Replace With: 98RH
 Kit: B6357
 Instructions: Doc #08-327



Mosler Magna
 Bag Only
 Replace: With 98RH
 Kit: B6379
 Instructions: 08-328



Allied – Nightwatch
 Dual
 Replace With: 98RH
 Kit: 96-440
 Instructions: N/A



American Vault – 85
 Replace With: 80UC
 Kit: B6883
 Instructions: N/A



Chubb/Diebold–
 Citadel
 Replace With: 80UC
 Kit: N/A
 Instructions: N/A



Collier – ND1000
 Replace With: 98RH
 Kit: 96-449
 Instructions: N/A



Collier – ND2000/
 ND2010
 Replace With: 80UC
 Kit: 96-475
 Instructions: N/A



Diebold Eagle
 Bag Only
 Replace With: 98RH
 Kit: Not Needed
 Instructions: N/A



Diebold–Eagle 103
 Dual Flush
 Replace With: 98RH
 Kit: None Needed
 Instructions: Doc
 #08-326



Diebold – Eagle 103
 Dual Recessed
 Replace With: 98RH
 Kit: N/A
 Instructions: N/A



Diebold – Polaris
 Flush
 Replace With: 98RH
 Kit: B6358
 Instructions: Doc
 #08-325



Diebold – Polaris
 Flush Bag Only
 Replace With: 98RH
 Kit: None Needed
 Instructions: N/A



Diebold – Polaris
 Recessed
 Replace With: 98RH
 Kit: B6406
 Instructions: N/A



Diebold –Securomatic
 Replace With: 80UC (98RH)
 Kit: 96-451 (B10374)
 Instructions: Doc
 #08-323

