



To adjust between BAG ONLY and ENVELOPE/BAG lock operation

- 1) Remove screws (1) and lock linkage cover (2) from side of frame.
- 2) Remove shoulder screw (3) from bottom of lock linkage.
- 3) Remove the locking pin from frame. Either (4) or (5) position.
- 4) Insert the locking pin:
 - a) Use the LOWER hole for ENVELOPE/BAG operation. Locking pin (4) with hole towards top.
 - b) Use the UPPER hole for BAG ONLY operation. Locking pin (5) with hole towards bottom.
- 5) Reinstall shoulder screw (3) through linkage into locking pin with a small amount of blue thread locker.
- 6) Test operation.
- 7) Reinstall linkage cover (2) with screws (1)

To adjust key stop in the locked position

This is to adjust where the key stops when locking the unit.

The key should stop in the locked position and remove easily.

- 1) If the key cannot be removed or is hard to remove adjust position of shoulder screw (6)
- 2) Loosen shoulder screw (6) so it can slide in the slot.
- 3) Put the key in the locked position and remove key.
- 4) Slide the shoulder screw (6) outwards until it stops.
 - a) Only apply slight pressure when sliding shoulder screw (6) outward.
- 5) Snug shoulder screw (6) in this position and test operation of keylock.
 - a) If key cannot be removed, slide shoulder screw (6) in slightly.
 - b) If key turns too far and must be turn back to remove, slide shoulder screw (6) out slightly.
- 6) When key operation is satisfactory, tighten shoulder screw (6)

est. 1967 HAMILTON CUSTOM MADE SECURITY	PROPRIETARY AND CONFIDENTIAL THESE DRAWINGS ARE THE PROPERTY OF HAMILTON SAFE CO. AND SHALL NOT BE REPRODUCED, COPIED, USED AS THE BASIS FOR MANUFACTURE OR SALE OF APPARATUS WITHOUT PERMISSION		TITLE Lock Adjustment, Oakley Night Depository Head	
	PART NUMBER OAK-LOCK-ADJ		DRAWN BY BilDef	
		DATE 8/4/2022	CHECKED BY	DATE
				REVISION