

Model CS-50 and CS-55

Headset Subscription

The headset and base unit are supplied subscribed to each other. However, if you wish to use a replacement headset with the base unit, then the units must be re-subscribed as follows:

Return the headset to the charging cradle.

- Press and hold both speaking volume fine tune buttons on the base unit for a minimum of 5 seconds. The power indicator will then flash red.
- Press and hold the headset mute button for a minimum of 5 seconds. The talk indicator light on the headset will then illuminate green.
 - Successful re-subscription is indicated when the base power indicator is fully illuminated and the headset talk indicator light is off.
- 3) Disconnect the AC charger from the AC charging jack for 5 seconds.
- 4) Reconnect the AC charger to the AC charging jack.
 - If re-subscription fails within 2 minutes, the headset will return to the un-subscribed state. Try the re-subscription process again or call Technical Support.

System Reset

To recover from some fault conditions, you may need to perform a system reset.

- 1) Press both the call control button and the listening volume/mute button for 5 seconds. When the talk indicator light blinks, release both buttons.
- 2) Press the call control button again. The talk indicator light will again blink briefly to indicate the headset is back to normal operation.
- Disconnect the AC charger from the AC charging jack for 5 seconds.
- 4) Reconnect the AC charger to the AC charging jack.

The system reset operation is complete.

